

## == DEMO1 ==

Before opening a sample packet

=====

- Different info popups by pressing buttons
- Quit button -> asks for confirmation
- Help button -> show how the search works

Open a simple sample packet

=====

- Open files in different formats
- HEX, BIN, ASCII buttons
- Define only necessary protocol information
- Define a field or two
- Defined bytes marked with red
- Saving the protocol tree
- Deleting a field
- Deleting the whole protocol tree

-----

Protocol info

Name: DEMO1

Description: Testing

Words	Field abbr	Type
They're taking	what	string
the hobbits	who	string
the	article	string
hobbits	noun	string
Isengard	where	string

- Create the fields in different order
- Save the protocol tree
- Choosing a field to be deleted
- Delete a subfield
- Delete a field with subfields
- Delete the whole protocol tree

## == DEMO2 ==

Protocol info

Name: DEMO2

Description: DEMO2 Test Protocol

Header length given: 15

Payload length from header field number: 1

Bytes	Type	Abbr	Name
0	uint8	f0	Message ID
1-2	uint16	f1	Payload length
3-8	bytes	f2	Source info
3-4	uint16	sf2-0	Source port
-> valuestring: [22]="SSH", [443]="HTTPS"			
-What if the given valstr is invalid?			
5-8	ipv4	sf2-1	Source IP
9-14	bytes	f3	Destination info
9-10	uint16	sf3-0	Destination port
-> valuestring: [22]="SSH", [443]="HTTPS"			
11-14	ipv4	sf3-1	Destination IP

-What if the user tries to define fields over the given header length?

15-> Payload part

Dissector table (parent): udp.port

-How the table name is checked from Wireshark?

Dissector ID (port): 55555

-What happens if the port number is invalid?

-What if only either one of them is given?

### == DEMO3 ==

Protocol info

Name: DEMO3

Description: My Test Protocol

Header delimiter: 0d0d

Payload length: all the remaining bytes

Field delimiter: 0d0a

Subfield delimiter: 20

-Field/subfield coloring

-Field/subfield choosing buttons

Field	Type	Abbr	Name
0	uint8	f0	Type
	-> valstr:	[0]="Response", [1]="Request"	
	-> bitmask:	0xFF0000	
1	string	f1	Message info
0	string	sf1-0	Method
1	string	sf1-1	Content
2	string	sf1-2	URI
3	string	sf1-3	Protocol version
2	string	f2	Host
->	Payload part		

Dissector table (parent): udp.port

Dissector ID (port): 12345

## **== DEMO4 ==**

Protocol info

Name: DEMO4

Description: DEMO4 Parent Protocol

Header length: last field

Payload delimiter: 0d0a

Field delimiter: 3a

<b>Field</b>	<b>Type</b>	<b>Abbr</b>	<b>Name</b>
0	uint16	f0	Port
	valstr: [194]="IRC", [6679]="IRC DEMO"		
	bitmask: 0xFFFF00		
1	string	f1	Server
->	Payload part (IRC channels)		

Dissector table (parent): tcp.port

Dissector ID (port): 9876

Dissector table (new): demo4.port

Subdissector ID

Field: 0

-Dissector file must be placed in .wireshark folder,  
not in the plugins folder.

-Line dofile("...") must be added to init.lua

-Show the dissection result before creating the  
dissector for the subprotocol

## **== DEMO5 ==**

Protocol info

Name: DEMO5

Description: DEMO5 Subprotocol

Header delimiter: 0d0a

Payload length: the rest

Field delimiter: 2c

<b>Field</b>	<b>Type</b>	<b>Abbr</b>	<b>Name</b>
0	string	ch1	Channel 1
1	string	ch2	Channel 2
2	string	ch3	Channel 3
3	string	ch4	Channel 4

-> No bytes left for payload anymore

Dissector table (parent): demo4.port

Dissector ID (port): 6679